

Food Stamp Purchase	Food Stamp Refund	Food Stamp Electronic Voucher
<ul style="list-style-type: none"> Press Until "EBT.....Sale" shows on the screen 	<ul style="list-style-type: none"> Press Until "EBT.....Sale" shows on the screen 	<ul style="list-style-type: none"> Press Until "EBT.....Sale" shows on the screen
<ul style="list-style-type: none"> Swipe EBT Card Or Enter Acct Number + 	<ul style="list-style-type: none"> Then Press <p>Screen will say "EBT.....Return"</p>	<ul style="list-style-type: none"> Then Press <p>Screen will say "EBT.....Forced"</p>
<ul style="list-style-type: none"> Press for Food Stamp 	<ul style="list-style-type: none"> Swipe EBT Card Or Enter Acct Number + 	<ul style="list-style-type: none"> Manually Enter Account Number +
<ul style="list-style-type: none"> Sale Amount + 	<ul style="list-style-type: none"> Enter Amount + 	<ul style="list-style-type: none"> Enter Amount +
<ul style="list-style-type: none"> Enter PIN Number + <p>Terminal Will Print a Receipt</p>	<ul style="list-style-type: none"> Enter PIN Number + <p>Terminal Will Print a Receipt</p>	<ul style="list-style-type: none"> Enter Auth Number +
<ul style="list-style-type: none"> Press then For Additional Receipt 	<ul style="list-style-type: none"> Press then For Additional Receipt 	<ul style="list-style-type: none"> Enter Voucher Number + <p>Terminal Will Print a Receipt</p>
Cash Benefits Purchase	Cash Benefits Cash Only Transaction	
<ul style="list-style-type: none"> Press Until "EBT.....Sale" shows on the screen 	<ul style="list-style-type: none"> Press Until "EBT.....Sale" shows on the screen 	
<ul style="list-style-type: none"> Swipe EBT Card Or Enter Acct Number + 	<ul style="list-style-type: none"> Swipe EBT Card Or Enter Acct Number + 	
<ul style="list-style-type: none"> = Food Stamp OR 	<ul style="list-style-type: none"> = Food Stamp OR 	
<ul style="list-style-type: none"> = Cash Benefits 	<ul style="list-style-type: none"> = Cash Benefits 	
<ul style="list-style-type: none"> Press for Cash Benefit 	<ul style="list-style-type: none"> Press for Cash Benefit 	
<ul style="list-style-type: none"> At "Enter Amount" Prompt, 		
<ul style="list-style-type: none"> Press 		
<ul style="list-style-type: none"> Cash Back + (Optional) 	<ul style="list-style-type: none"> Cash Back + (Enter the cash only amount here) 	
<ul style="list-style-type: none"> Enter PIN Number + 	<ul style="list-style-type: none"> Enter PIN Number + 	
<ul style="list-style-type: none"> Terminal Will Print a Receipt 	<ul style="list-style-type: none"> Terminal Will Print a Receipt 	
<ul style="list-style-type: none"> Press then For Additional Receipt 	<ul style="list-style-type: none"> Press then For Additional Receipt 	

NOTE:**EBT INFORMATION / DEFINITIONS:**

Electronic Voucher: A form completed by merchant for a Food Stamp transaction if the terminal is unable to complete a Food Stamp Purchase Transaction. Merchant also calls for Voice approval then completes the Electronic Voucher transaction above when the terminal is able to communicate.

Voucher Serial Number: A Serial Number is pre-printed on every voucher form and this number must be entered during the Electronic Voucher Transaction.

Food Stamp and Cash Benefits: Some merchants will process only Food Stamps transactions, some will accept only Cash Benefit transactions, and some will accept both. This is determined by the arrangement the merchant signs with the Food and Nutrition Services.

Available Balance: The available balance on the customer's EBT card will print at the bottom of all receipts.

OPTIONAL TERMINAL PROMPTS:

Optional Terminal prompts may appear during EBT transactions based on the terminal application.

Optional prompts include: Clerk or Server Number, Invoice Number, and Password.