
















































Food Stamp Purchase	Cash Benefits	Food Stamp Refund
<ul style="list-style-type: none"> › Swipe EBT Card Or Press  › Manually Enter Acct Number › Press  › Press  › Press  › Enter Invoice Number* +  › Enter Server ID* +  › Confirm Total on PIN Pad* › Press  › Customer Enters PIN › Press  	<ul style="list-style-type: none"> › Swipe EBT Card Or Press  › Manually Enter Acct Number › Press  › Press  › Press  › Enter Invoice Number* +  › Enter Server ID* +  › Confirm Total on PIN Pad* › Press  › Customer Enters PIN › Press  	<ul style="list-style-type: none"> › Press  › Enter Password* +  › Swipe EBT Card Or Manually Enter Acct Number › Press  › Press  › Enter Invoice Number* +  › Enter Server ID* +  › Amount +  › Confirm Total on PIN Pad* › Press  › Customer Enters PIN › Press 
<h3>Food Stamp Electronic Voucher*</h3>		
<ul style="list-style-type: none"> › Call Voice Authorization Center and Record Code on Form › Swipe EBT Card Or Press  › Manually Enter Acct Number › Press  › Press  › Press  › Enter Invoice Number* +  › Enter Server ID* +  › Voucher App Code: › Press  › Voucher S/N: (Enter From Voucher) › Press  › Amount +  		

NOTE:

- Enter *Password* When Prompted
- * If using an internal PIN pad, skip this step.
- › Optional prompts may occur according to what selections are turned on within the application.
- * Manually Only

Offline*

- › Press 
- › Manually Enter Acct Number
- › Press 
- › Press 
- › Press Appropriate Transaction Type
- › Enter Invoice Number* + 
- › Enter Server ID* + 
- › Network ID: 
- › Settlement Date: MMY
- › Press 
- › Original Transaction Date: MMY
- › Press 
- › Original Time: HHMMSS
- › Press 
- › Original Trace Number
- › Press 
- › Retrieval Number:
- › Press 
- › Appr Code:
- › Press 
- › Amount + 

EBT Information

- › **Electronic Voucher** – Used for Food Stamp transaction when the terminal cannot obtain authorizations. Merchant completes form.
- › **Offline Function** – Used when the terminal has lost all transactions. Only used when instructed by Help Desk.
- › **Voucher S/N** – Found on pre-printed form.
- › **Voucher Appr Code** – Received from Voice Authorization for a Food Stamp transaction.
- › **FNS ID** – Food and Nutrition Services Identifier. ID for merchant approved to accept Food Stamps.

NOTE:

Pressing the 3 key from the main menu on the Omni 3750 will advance the paper.

- Enter *Password* When Prompted

* If using an internal PIN pad, skip this step.

› Optional prompts may occur according to what selections are turned on within the application.

* Manually Only